
Social Booth Settings - Printing

Modified on: Sun, 12 Jul, 2015 at 7:00 AM



(http://imgur.com/068XIbr)

1.

Auto Print

Enable this to have photos automatically print when the session is complete.

2. Auto Print Copies


This is the number of copies of photos to print when auto print is enabled.

3. Enable Print Button

Enabling the Print button will show the print button on the Share screen along with the upload options.

4. Max # Prints to Choose

Setting this to anything greater than 1 will show the user a dialog box asking them how many copies of the print they want. The number set here will be the maximum number of prints they will be allowed.



(https://s3.amazonaws.com/cdn.freshdesk.com/data/helpdesk/attachments/production/3010935263/original/blob1436724009791.png? 1436724019)

5. Max # Prints/Event

This allows you to disable all printing after a certain # of prints have been reached. Leave this set to 0 for unlimited prints unless you plan on limiting the # of prints at the event.

6. **Print 1/2 # copies**

This feature is useful if you are printing strips where 14x6 usually ends up getting cut into 2. When this is enabled, when a user selects 2 copies, only 14x6 will be printed, and it is assumed the printer will be cutting it into 2 copies for the user.

7. Rotate Print 90

This will rotate the print by 90 degrees before printing.

8. Require Share to Print

This will require a user to share the photo to social media, email or SMS before they can print. The print icon will be transparent (like in the screen shot above) until the photo is shared.

9–11 **Printer Tweaks**

It shouldn't be necessary to change these values, but if you can't get the photo to print properly, adjust the scale and the margins in small increments so you can see the effect.